



AN ORIGINAL GRANITE BRACKET PRODUCT  
**THE ORIGINAL FLOATING SHOWER BENCH KIT®**  
with GoBoard®



**1. Install brackets at the desired height using the provided hardware. Ensure they are level and securely attached.**



**2. Install preferred backer board to manufacturer specifications.**



**3. Notch brackets into 1st board. Apply adhesive to the brackets. Set the board onto the brackets.**



**4. Apply adhesive to the first board.**



**5. Attach the second board to the first board.**



**6. Apply a layer of thin-set and wrap the exposed sides and brackets with provided Tape.**



**7. Apply thin-set and your choice of finished product.**

[floatingshowerbench.com](http://floatingshowerbench.com)

