



THE ORIGINAL
GRANITE BRACKET

HIDDEN ISLAND

SUPPORT BRACKET

The Hidden Island Support Bracket is designed to attach to the inside of the front wall of the cabinet (where the doors of the cabinet are) & will extend through the cabinet to support the countertop overhang.



THE ORIGINAL
GRANITE BRACKET®

originalgranitebracket.com
888-584-1112

WATCH OUR INSTALLATION VIDEO

<https://originalgranitebracket.com/pages/installation-videos>

SAFETY INSTRUCTIONS

- Use the correct tools.
- Wear safety goggles & proper safety equipment.
- Follow fixture, power tools & paint manufactures instructions & user manuals.
- Use common sense & follow good construction practices.
- Consult a professional when installing brackets for load bearing application.
- Be sure the bracket has a substructure that is able to support the bracket & any other additional weight that may be added to it.
- When in doubt, consult a professional installer.

Installation Guide:

Step #1:

Start 3"-6" inches from the edge of the back side of the cabinet. Next, notch out a 2.5" x 0.5" pocket on the backside of the cabinet, for the bracket to rest into. (This will be on the side of the cabinet where the overhang of the countertop.)

Step #2:

This "pocket" will allow the Hidden Island Support Bracket to sit flush with the top of the cabinet.

NOTE: It is important that the bracket be flush with the cabinet in order for the countertop to sit level & to protect the countertop.

Step #3:

Make your next notch for the next bracket 16"-20" from the first notch. Then space each of the brackets 16"-20" apart for countertop protection.

Step #4:

Attach the flange of the bracket to the inside of the front of the cabinet (where the doors are) with appropriate wood screws. The bracket will not interfere.

NOTE: We have provided screws **HOWEVER** make sure the length of the provided screws are appropriate for your project. If not appropriate **DO NOT** use the screws provided. Each project is different so protect your project by measuring before you add the screws.

Step #5:

The bracket will rest inside the notch you made supporting the countertop overhang. The bracket should be flush with the top of the cabinet in order to protect your countertop & allow your countertop to sit level.

Step #6:

Place the countertop on top of the cabinet & brackets, then simply caulk around the brackets with clear silicone.

