



Installation Instructions for RodKat Shower Trays, Wedge and Curbs

The substrate below the RodKat shower tray, wedge or curb must be level, clean and load bearing to current industry standards and applicable building codes.

Your RodKat shower tray can be installed before or after the wall substrate is installed.

- Dry fit the RodKat shower tray to guarantee proper fit and orientation.
- Apply any industry approved thin-set mortar to the substrate using a 3/8" x 3/8" (10 mm x 10mm) square or U-notched trowel. Key thin-set onto the back of the shower tray using the flat side of the trowel to assure 100% coverage.
- Place the RodKat shower tray down and embed the tray solidly into the mortar.

Note: Walking on the surface will embed the shower tray.

When there is plumbing access from below, the drain and drainpipe can be prepared and installed after the installation of the RodKat shower tray.

When there is no plumbing access from below, the drain is measured and dry fitted before the installation of the RodKat shower tray. The drain is then installed to the appropriate height and connected to the waste line after installation of the RodKat shower tray.

RodKat shower components ARE NOT WATERPROOF nor are they wear surfaces.

IMPORTANT: All exposed areas must be waterproofed following manufacturers' waterproofing instructions, ANSI specifications, industry standards, and by applicable building codes for the finish selected by the user.