


No. 777 Toe-Kick Saw**NO. 777 TOE-KICK SAW**

Order No.	Description
1775-10	Blade Driver
1777-10	Depth Lock Nut
1777-11	Depth Adjuster & Fasteners (5)
1777-12	Motor
1777-13	Brush Set (not shown)
1777-14	Power Cord (not shown)
1777-15	Carrying Case (not shown)
1785-C	Return Spring
1785-E	Blade Guard Retainer Ring
1795-P	Primary Blade Guard
1795-R	Secondary Guard Return Spring
1795-S	Secondary Guard
1795-T	Secondary Guard Washer
1795-U	Secondary Guard Screw
1795-V	Power Cord Strain Relief (not shown)
1800-U	Socket Set Screw
1800-V	Hex Key Wrench
1820-R1	Switch Type B, Black (not shown)