

WOOD SURFACE CLEANER

WOODCARE PRO

ALL WOOD SURFACES



WHAT IT'S FOR

- Deep cleans all wood floors.
- Maintains the surface's natural beauty.
- Perfect for all wood surfaces: tables, doors, furniture, baseboards.

ADVANTAGES

- Dries fast.
- No rinsing necessary.
- No streaks.
- Does not damage surfaces
- Neutral on surfaces.
- Contains biodegradable ingredients.
- Interior and exterior use.

HOW TO USE IT

Spray **WOODCARE PRO** directly on the surface and wipe with a clean, damp cloth or microfiber mop.
The product dries quickly, no rinsing required.

Storage temperature: between 41°F and 86°F (5°C and 30°C).
Must be applied at temperatures between 50°F and 86°F (10°C and 30°C).

- **DRIES FAST.**
- **NO RESIDUE.**
- **NO STREAKS.**



Coverage:

24 OZ (710 ml)
up to 2,153 sq. ft. (200 m²)
Coverage rates are indicative.



Packaging:

24 OZ (710 ml) 6 spray bottles per box